

The above is a suggested direct water set-up configuration for High Volume (10+ Polycarbonate jobs per day) and should only be implemented by a licensed plumber. Santinelli International assumes no direct or indirect responsibility for set-up and/or functionality.

