

1. Clean all debris that may be inside the tracer or grinding chamber.

2. Open main tracer lid and slide open tracer doors.

3. Place one strip of masking tape in front and one in back of stylus. (Tape should extend entire length of tracer.)

4. Insert tracer packing foam into tracer, aligning hole in foam with stylus tip.

5. Locate hole in lower center of left edger panel. Using a 3mm Allen wrench, insert packing screw and turn clockwise until screw is in locked position.

6. Turn drain line counter-clockwise and remove.

7. Pull off feed lines.

8. Using accessory checklist as guide, collect all accessories and return to original stations within black accessory kit box.

9. Tape both edger grinding chamber and tracer cover in place for shipping.

9. Remove top half of edger packing foam.

10. Place edger into bottom half of edger foam in the carton. (TWO PEOPLE MAY BE NEEDED FOR THIS STEP)

11. Cover edger with top half of edger packing foam.

12. Place all edger accessories on top of packing foam.

13. Close box and secure with packing tape.

14. Affix return shipping label on top of carton and follow instruction sheet to arrange for pick-up.

