



- 1- Power down the edger and unplug the power cord.
- 2- Remove the edger cover (See FAQ “How do I remove the Top Cover?”)
- 3- Loosen 4 (four) allen screws as indicated in pictures. (2 are in front of tracer on silver plate and 2 are in rear of tracer unit located on lower bracket).
- 4- Remove P1101 cable connected on rear of tracer unit.
- 5- Place left hand on round black motor on left side of tracer and right hand on the right side of tracer. Gently lift the front of tracer up and slide tracer unit towards you.
- 6- Clean silver plate that now remains on edger.
- 7- The new tracer to be installed has a similar shipping plate connected to it follow steps 3 and 4 to remove new tracer from the silver shipping plate.
- 8- Once silver plate has been removed from new tracer, carefully take the tracer and slide the back end into allen screws on silver plate on edger and gently lower front portion of tracer. Make sure that the allen screws on the front of the tracer slip into the grooves on the silver plate.
- 9- Tighten all (4) four allen screws and reconnect the P1101 connection of back of tracer.
- 10- Remove foam and masking tape located in tracer unit.
- 11- Pack old or defective tracing unit in same fashion the new tracer arrived..
- 12- Place cover back on edger and connect CA03 cable (green and grey) in rear for control panel.
NOTE: CA03 Cable has 1 red wire that should be on top of cable assembly when reconnecting. Turn on edger. If display panel is dim or not visible, Turn off edger and disconnect the CA03 cable and reconnect again allowing tabs to come closed independently.
- 13- Cut several lenses to ensure that size and axis on beveled and rimless lenses are good. If retouch is necessary, please retouch lens until it fits. Once lens fits properly in frame, make note of amount of retouch necessary to make lens fit and contact Santinelli's Technical Help Desk for size adjustment and RMA number.